

## RollerCoaster Hire Safety Guidelines



1. Children must be supervised using the equipment at all times.
2. For indoor / dry outdoor use.
3. No food or drink to be consumed on the equipment.
4. Only the car that comes with the roller coaster should be used on the ride.
5. Please ensure children don't stand on or in front of the roller coaster.
6. Please ensure there is sufficient run off room.
7. Children should not climb the steps until the car is in place with wheels in the grooves.
8. The roller coaster is for the use of children between 2 and 5 years.